



# Original operating manual

Rotary harrow

KE 6002-2



SmartLearning



 <b>AMAZONE</b>	AMAZONEN-WERKE H. DREYER SE & Co. KG Am Amazonenwerk 9-13 D-49205 Hasbergen
Serial no. <input type="text"/>	
Vehicle ID no. <input type="text"/>	
Product <input type="text"/>	
Permissible technical implement weight kg <input type="text"/>	Model year <input type="text"/>

Please enter the identification data of the implement. The identification data can be found on the rating plate.



# TABLE OF CONTENTS

<b>1</b>	<b>About this operating manual</b>	<b>1</b>	4.5.2	Layout of the warning symbols	26
1.1	Copyright	1	4.5.3	Description of the warning symbols	27
1.2	Diagrams	1	<b>4.6</b>	<b>Threaded cartridge</b>	<b>31</b>
1.2.1	Warnings and signal words	1	<b>4.7</b>	<b>Three-point mounting frame</b>	<b>32</b>
1.2.2	Further instructions	2	<b>4.8</b>	<b>Rating plate on the implement</b>	<b>32</b>
1.2.3	Instructions	2	<b>4.9</b>	<b>Universal operating tool</b>	<b>33</b>
1.2.4	Lists	4	<b>4.10</b>	<b>Universal joint shaft locking mechanism</b>	<b>33</b>
1.2.5	Item numbers in figures	4	<b>4.11</b>	<b>Lighting and identification for road travel</b>	<b>34</b>
1.2.6	Direction information	4	4.11.1	Rear lighting and identification for road travel	34
<b>1.3</b>	<b>Other applicable documents</b>	<b>4</b>	4.11.2	Front lighting and identification for road travel	34
<b>1.4</b>	<b>Digital operating manual</b>	<b>4</b>	4.11.3	Additional license plate	35
<b>1.5</b>	<b>Your opinion is important</b>	<b>4</b>	<b>4.12</b>	<b>Rollers</b>	<b>35</b>
			4.12.1	AMAZONE rollers	35
			4.12.2	Packer rollers from other manufacturers	36
<b>2</b>	<b>Safety and responsibility</b>	<b>5</b>	<b>5</b>	<b>Technical data</b>	<b>37</b>
2.1	Basic safety instructions	5	<b>5.1</b>	<b>Dimensions</b>	<b>37</b>
2.1.1	Safe operating organisation	5	<b>5.2</b>	<b>Permissible total weight</b>	<b>37</b>
2.1.2	Knowing and preventing dangers	9	<b>5.3</b>	<b>Mounting category</b>	<b>37</b>
2.1.3	Safe operation and handling of the machine	12	<b>5.4</b>	<b>Forward speed</b>	<b>37</b>
2.1.4	Safe maintenance and modification	14	<b>5.5</b>	<b>Working depth</b>	<b>38</b>
<b>2.2</b>	<b>Safety routines</b>	<b>18</b>	<b>5.6</b>	<b>Performance characteristics of the tractor</b>	<b>38</b>
			<b>5.7</b>	<b>Noise development data</b>	<b>38</b>
<b>3</b>	<b>Intended use</b>	<b>20</b>	<b>5.8</b>	<b>Drivable slope inclination</b>	<b>39</b>
			<b>5.9</b>	<b>Lubricants</b>	<b>39</b>
<b>4</b>	<b>Product description</b>	<b>21</b>	<b>5.10</b>	<b>Oils and filling capacities</b>	<b>39</b>
4.1	Implement overview	21	<b>5.11</b>	<b>Permissible payload</b>	<b>41</b>
4.2	Function of the implement	22	<b>6</b>	<b>Preparing the machine</b>	<b>42</b>
4.3	Special equipment	23	6.1	Calculating the required tractor characteristics	42
4.4	Protective equipment	23			
4.4.1	Universal joint shaft guard	23			
4.4.2	Tool protection	24			
4.4.3	Frame transport lock	24			
4.4.4	Roller transport lock	25			
<b>4.5</b>	<b>Warning symbols</b>	<b>25</b>			
4.5.1	Positions of the warning symbols	25			

## TABLE OF CONTENTS

<b>6.2</b>	<b>Attaching the backstop profiles for the lower links</b>	<b>45</b>	<b>9</b>	<b>Parking the machine</b>	<b>66</b>
<b>6.3</b>	<b>Installing the universal joint shaft on the implement</b>	<b>46</b>	<b>9.1</b>	<b>Unfolding the implement</b>	<b>66</b>
<b>6.4</b>	<b>Coupling the implement</b>	<b>47</b>	<b>9.2</b>	<b>Lowering the implement</b>	<b>67</b>
6.4.1	Driving the tractor towards the implement	47	<b>9.3</b>	<b>Uncoupling the lighting for road travel</b>	<b>67</b>
6.4.2	Coupling the three-point extension	47	<b>9.4</b>	<b>Disconnecting the hydraulic hose lines</b>	<b>68</b>
6.4.3	Coupling the three-point mounting frame	48	<b>9.5</b>	<b>Uncoupling the universal joint shaft</b>	<b>68</b>
6.4.4	Coupling the hydraulic hose lines	48	<b>9.6</b>	<b>Uncoupling the three-point mounting frame</b>	<b>69</b>
6.4.5	Coupling the lighting for road travel	50			
6.4.6	Coupling the universal joint shaft	50			
6.4.7	Calculating the permissible payload	50	<b>10</b>	<b>Repairing the machine</b>	<b>70</b>
<b>6.5</b>	<b>Preparing the implement for operation</b>	<b>51</b>	<b>10.1</b>	<b>Maintaining the machine</b>	<b>70</b>
6.5.1	Manual adjustment of the tine working depth	51	10.1.1	Maintenance schedule	70
6.5.2	Adjusting the working height of the levelling board	52	10.1.2	Checking the lower link pins and top link pins	71
6.5.3	Adjusting the working depth of the side guide plates	53	10.1.3	Checking the hydraulic hose lines	71
6.5.4	Adjusting the spring tension of the side guide plates	55	10.1.4	Checking the tines	72
6.5.5	Adjusting the speed of the tines	56	10.1.5	Replacing the tines	73
6.5.6	Using the centre line eradicator	57	10.1.6	Checking and adjusting the scraper on the roller	74
6.5.7	Adjusting the section end position	58	10.1.7	Checking the oil level in the interchangeable wheel gear	75
6.5.8	Adjusting the scraper on the roller	58	10.1.8	Checking the oil level in the centre gearbox	76
<b>6.6</b>	<b>Preparing the machine for road travel</b>	<b>59</b>	10.1.9	Checking the oil level in the spur gear trough	77
6.6.1	Folding the implement	59	10.1.10	Replacing the oil in the interchangeable wheel gear	78
6.6.2	Switching off the work lights	60	10.1.11	Replacing the oil in the centre gearbox	78
<b>7</b>	<b>Using the machine</b>	<b>61</b>	10.1.12	Ratchet clutch maintenance	80
7.1	Unfolding the implement	61	10.1.13	Universal joint shaft maintenance	80
7.2	Using the implement	61	<b>10.2</b>	<b>Lubricating the implement</b>	<b>81</b>
7.3	Checking the set working depth	62	10.2.1	Overview of lubrication points	82
7.4	Turning on the headlands	62	<b>10.3</b>	<b>Cleaning the implement</b>	<b>83</b>
			<b>10.4</b>	<b>Storing the implement</b>	<b>84</b>
<b>8</b>	<b>Eliminating faults</b>	<b>63</b>			
			<b>11</b>	<b>Loading the implement</b>	<b>85</b>
			11.1	Loading the implement with a crane	85

<b>11.2</b>	<b>Manoeuvring the implement onto a transport vehicle</b>	<b>85</b>
<b>11.3</b>	<b>Lashing the implement</b>	<b>86</b>

<b>12</b>	<b>Disposing of the implement</b>	<b>87</b>
-----------	-----------------------------------	-----------

<b>13</b>	<b>Appendix</b>	<b>88</b>
-----------	-----------------	-----------

<b>13.1</b>	<b>Bolt tightening torques</b>	<b>88</b>
<b>13.2</b>	<b>Other applicable documents</b>	<b>89</b>

<b>14</b>	<b>Directories</b>	<b>90</b>
-----------	--------------------	-----------

<b>14.1</b>	<b>Glossary</b>	<b>90</b>
<b>14.2</b>	<b>Index</b>	<b>91</b>



# About this operating manual

# 1

CMS-T-00000081-K.1

## 1.1 Copyright

CMS-T-00012308-A.1

Reprinting, translation and reproduction in any form, including excerpts, require the written approval of AMAZONEN-WERKE.

## 1.2 Diagrams

CMS-T-005676-G.1

### 1.2.1 Warnings and signal words

CMS-T-00002415-A.1

Warnings are marked with a vertical bar with a triangular safety symbol and the signal word. The signal words "*DANGER*", "*WARNING*" or "*CAUTION*" describe the severity of the potential danger and have the following meanings:



#### **DANGER**

- ▶ Indicates a direct threat with high risk for severe physical injury, such as loss of limbs or death.



#### **WARNING**

- ▶ Indicates a possible threat with moderate risk for severe physical injury or death.



#### **CAUTION**

- ▶ Indicates a threat with low risk for light or moderately severe physical injuries.

## 1.2.2 Further instructions

CMS-T-00002416-A.1



### IMPORTANT

- ▶ Indicates a risk for damage to the implement.



### ENVIRONMENTAL INFORMATION

- ▶ Indicates a risk for environmental damage.



### NOTE

Indicates application tips and instructions for optimal use.

## 1.2.3 Instructions

CMS-T-00000473-E.1

### 1.2.3.1 Numbered instructions

CMS-T-005217-B.1

Actions that have to be performed in a specific sequence are represented as numbered instructions. The specified sequence of the actions must be observed.

Example:

1. Instruction 1
2. Instruction 2

### 1.2.3.2 Instructions and responses

CMS-T-005678-B.1

Reactions to instructions are marked with an arrow.

Example:

1. Instruction 1
- ➔ Reaction to instruction 1
2. Instruction 2

### 1.2.3.3 Alternative instructions

CMS-T-00000110-B.1

Alternative instructions are introduced with the word "or".

Example:

1. Instruction 1

or

Alternative instruction

2. Instruction 2

### 1.2.3.4 Instructions with only one action

CMS-T-005211-C.1

Instructions with only one action are not numbered, but rather shown with a arrow.

Example:

▶ Instruction

### 1.2.3.5 Instructions without sequence

CMS-T-005214-C.1

Instructions that do not require a specific sequence are shown as a list with arrows.

Example:

▶ Instruction

▶ Instruction

▶ Instruction

### 1.2.3.6 Workshop work

CMS-T-00013932-B.1

 **WORKSHOP WORK**

- ▶ Identifies maintenance work that must be performed at a workshop that is adequately equipped in terms of agricultural technology, safety and environmental technology by specialist personnel with appropriate training.

## 1.2.4 Lists

CMS-T-000024-A.1

Lists without an essential order are shown as a list with bullets.

Example:

- Point 1
- Point 2

## 1.2.5 Item numbers in figures

CMS-T-000023-B.1

A framed number in the text, e.g. a 1, indicates an item number in an adjacent figure.

## 1.2.6 Direction information

CMS-T-00012309-A.1

Unless otherwise specified, all directions are always seen in the direction of travel.

## 1.3 Other applicable documents

CMS-T-00000616-B.1

A list of other applicable documents can be found in the Appendix.

## 1.4 Digital operating manual

CMS-T-00018782-A.1

The digital operating manual and e-learning can be downloaded from the Download Center on the AMAZONE website.

## 1.5 Your opinion is important

CMS-T-000059-D.1

Dear reader, our documents are updated on a regular basis. Your suggestions for improvement help us to create ever more user-friendly documents. Please send us your suggestions by post, fax or email.

AMAZONEN-WERKE H. Dreyer SE & Co. KG  
Technische Redaktion  
Postfach 51  
D-49202 Hasbergen  
Fax: +49 (0) 5405 501-234  
E-Mail: [tr.feedback@amazone.de](mailto:tr.feedback@amazone.de)

CMS-I-00000638

# Safety and responsibility

# 2

CMS-T-00004173-J.1

## 2.1 Basic safety instructions

CMS-T-00004174-J.1

### 2.1.1 Safe operating organisation

CMS-T-00002302-E.1

#### 2.1.1.1 Personnel qualification

CMS-T-00002306-C.1

##### 2.1.1.1.1 Requirements for persons working with the implement

CMS-T-00002310-C.1

**If the implement is used improperly, people can be injured or killed: To prevent accidents due to improper use, every person who works with the implement must meet the following minimum requirements:**

- The person is physically and mentally capable of controlling the machine.
- The person can safely perform work with the machine within the scope of this operating manual.
- The person understands the functioning of the machine within the scope of their work and can recognise and prevent dangers arising during operation.
- The person had understood the operating manual and can implement the information that is conveyed in the operating manual.
- The person must be familiar with safe driving of vehicles.
- For road travel, the person knows the relevant road traffic regulations and has the prescribed driving permit.

#### **2.1.1.1.2 Qualification levels**

CMS-T-00002311-A.1

**For working with the machine, the following qualification levels are provided:**

- Farmer
- Agricultural helper

As a matter of principle, the activities described in this operating manual can be performed by persons with the qualification level "Agricultural helper".

#### **2.1.1.1.3 Farmer**

CMS-T-00002312-A.1

Farmers use agricultural implement to cultivate fields. They decide on the use of an implement for a specific purpose.

Farmers are basically familiar with working with agricultural implements and can instruct agricultural helpers in how to use the implements if necessary. They can perform odd tasks and simple maintenance and repair work on agricultural implements themselves.

**Farmers can be e.g.:**

- Farmers with higher education or training from a technical college
- Farmers by experience (e.g. inherited farm, comprehensive practical knowledge)
- Contractors who work by order of farmers

**Activity example:**

- Safety training for agricultural helpers

#### **2.1.1.1.4 Agricultural helpers**

CMS-T-00002313-A.1

Agricultural helpers use agricultural implements by order of the farmer. They are instructed on the use of the implement by the farmer, and work independently according to the work assignment from the farmer.

**Agricultural helpers can be e.g.:**

- Seasonal workers and labourers
- Prospective farmers in training
- Employees of the farmer (e.g. tractor driver)
- Family members of the farmer

**Activity examples:**

- Driving the machine
- Adjusting the working depth

**2.1.1.2 Workplaces and passengers**

CMS-T-00002307-B.1

**Passengers**

Passengers can fall, be run over and severely injured or killed due to machine movements. Ejected objects can hit and injure passengers.

- ▶ Do not let anybody ride on the machine.
- ▶ Do not let anybody climb onto the driving machine.

**2.1.1.3 Danger for children**

CMS-T-00002308-A.1

**Danger for children**

Children cannot assess dangerous situations and can behave unpredictably. As a result, children are at a higher risk.

- ▶ Keep children away.
- ▶ *When you drive out or actuate machine movements,* make sure that there are no children in the danger area.

**2.1.1.4 Operational safety**

CMS-T-00002309-D.1

**2.1.1.4.1 Perfect technical condition**

CMS-T-00002314-D.1

**Only use properly prepared machines**

Without correct preparation according to this operating manual, operational safety of the machine is not ensured. This can result in accidents and serious personal injury or even death.

- ▶ Prepare the machine according to this operating manual.

### **Danger due to damage to the machine**

Damage to the machine can impede the operational safety of the machine and cause accidents. This can result in serious injury or death.

- ▶ *If you suspect or observe damage:*  
Secure the tractor and machine.
- ▶ Repair safety-relevant damage immediately.
- ▶ Fix the damage according to this operating manual.
- ▶ *If you are not able to fix the damage according to this operating manual yourself:*  
Have the damage repaired by a qualified specialist workshop.

### **Observe the technical limit values**

Non-observance of the technical limit values of the machine can result in accidents and serious personal injury or even death. Moreover, the machine can be damaged. The technical limit values can be found in the Technical Data.

- ▶ Comply with the technical limit values.

#### **2.1.1.4.2 Personal protective equipment**

CMS-T-00002316-B.1

### **Personal protective equipment**

Wearing personal protective equipment is an important safety element. Missing or unsuitable personal protective equipment increases the risk of damage to health and personal injury. Personal protective equipment includes: work gloves, safety shoes, protective clothing, breathing protection, hearing protection, face protection, and eye protection

- ▶ Determine the personal protective equipment required for each job and have it ready.
- ▶ Use only protective equipment that is in proper condition and offers effective protection.
- ▶ Adjust the personal protective equipment to the person, e.g. the size.
- ▶ Observe the manufacturer's instructions regarding operating materials, seed, fertiliser, crop protection products, and cleaning agents.

### Wear suitable clothing

Loosely worn clothing increases the risk of getting caught or entangled on rotating parts and getting stuck on protruding parts. This can result in serious injury or death.

- ▶ Wear close-fitting, snag-free clothes.
- ▶ Never wear rings, necklaces and other jewellery.
- ▶ *If you have long hair,*  
wear a hairnet.

#### 2.1.1.4.3 Warning symbols

CMS-T-00002317-B.1

### Keep warning symbols legible

Warning symbols on the machine warn you of risks in danger areas and are an important element of the machine's safety equipment. Missing warning symbols increase the risk of serious and lethal personal injury.

- ▶ Clean dirty warning symbols.
- ▶ Immediately replace any damaged and illegible warning symbols.
- ▶ Put the intended warning symbols on spare parts.

#### 2.1.2 Knowing and preventing dangers

CMS-T-00004917-E.1

##### 2.1.2.1 Safety hazards on the implement

CMS-T-00002318-G.1

### Liquids under pressure

Escaping high pressure hydraulic fluid can penetrate into the body through the skin and cause serious personal injuries. A hole the size of a needle can already result in serious personal injuries.

- ▶ *Before you uncouple the hydraulic hose lines or check for damage,*  
depressurise the hydraulic system.
- ▶ *If you suspect damage on a pressure system,*  
have the pressure system checked by a qualified specialist workshop.
- ▶ Never look for leaks with your bare hands.
- ▶ Keep your body and face away from leaks.
- ▶ *If liquids penetrate the body,*  
consult a doctor immediately.

### **Hydraulic accumulator**

Hydraulic accumulators contain gas under pressure. There is a risk of explosion if they are not handled properly.

- ▶ Do not make any modifications on hydraulic accumulators.
- ▶ Have hydraulic accumulators checked and serviced as specified in the operating manual.

### **Risk of injury on the universal joint shaft**

Persons can be caught, pulled in and severely injured by the universal joint shaft and driven components. If the universal joint shaft is overloaded, the implement can be damaged, parts can be ejected at high speed, and persons can be injured.

- ▶ Maintain sufficient coverage of the profile tube, universal joint shaft guard and PTO shaft protective cap.
- ▶ Maintain the direction of rotation and the permissible speed of the universal joint shaft.
- ▶ *If the universal joint shaft is angled down too strongly:*  
Switch off the universal joint shaft drive.
- ▶ *If you do not need the universal joint shaft:*  
Switch off the universal joint shaft drive.

### **Risk of injury on the PTO shaft**

Persons can be caught, pulled in and severely injured by the PTO shaft and driven components. If the PTO shaft is overloaded, the implement can be damaged, parts can be ejected at high speed, and persons can be injured.

- ▶ Maintain sufficient coverage of the profile tube, universal joint shaft guard and PTO shaft protective cap.
- ▶ Allow the locks on the PTO shaft to engage.
- ▶ *To secure the universal joint shaft guard against rotating:*  
Hook on the safety chains.
- ▶ *To secure the coupled hydraulic pump against rotating:*  
Put on the torque support.
- ▶ Maintain the direction of rotation and the permissible speed of the PTO shaft.
- ▶ *To prevent implement damage due to torque peaks:*  
Slowly couple the PTO shaft at low tractor engine speed.

### Danger due to machine parts still running

When the drives are switched off, machine parts can continue running and cause serious personal injury or death.

- ▶ Before approaching the machine, wait until any machine parts that are still running have come to a stop.
- ▶ Only touch machine parts that are standing still.

### 2.1.2.2 Danger areas

#### Dangers areas on the machine

The following basic dangers are encountered in the danger areas:

The implement and its work tools move during operation.


Hydraulically raised machine parts can descend unnoticed and slowly.

The tractor and implement can roll away unintentionally.

Materials or foreign objects can be ejected out of or away from the implement.

If the danger area is not observed, it can result in serious personal injury or death.

- ▶ Keep people out of the danger area of the machine.
- ▶ *If people enter the danger area, immediately switch off the engines and drives.*
- ▶ *Before you work in the danger area of the implement, secure the tractor and implement. This also applies for quick checking work.*



CMS-T-00004918-B.1

CMS-I-00003509

### 2.1.3 Safe operation and handling of the machine

CMS-T-00002304-M.1

#### 2.1.3.1 Coupling implements

CMS-T-00002320-D.1

##### **Coupling the implement on the tractor**

Incorrectly coupling of the implement to the tractor results in hazards that can cause serious accidents.

There are crushing and shear points in the area of the coupling points between the tractor and the implement.

- ▶ *If you couple or uncouple the implement to or from the tractor, be very careful.*
- ▶ Use only suitable tractors for coupling and transporting the implement.
- ▶ *When the implement is coupled onto the tractor, make sure that the tractor's connecting device meets the implement requirements.*
- ▶ Couple the implement properly to the tractor.

### 2.1.3.2 Driving safety

CMS-T-00002321-I.1

#### **Risk when driving on roads and fields**

Any mounted or towed implement as well as front or rear ballast weights on the tractor influence the driving behaviour and the steering and braking power of the tractor. The driving characteristics also depend on the operating condition, the fill level of the load, and on the ground. If the driver does not take account of changing driving characteristics, he can cause accidents.

- ▶ Always ensure that the tractor's steering and braking systems are operating correctly.
- ▶ *The tractor must provide the required brake lag for the tractor and mounted implement.*  
Check the function of the brakes before moving off.
- ▶ *The tractor front axle must always be loaded with at least 20 % of the empty tractor weight to ensure sufficient steering capacity.*  
Use front ballast weights if necessary.
- ▶ Always attach the front or rear ballast weights properly on the specified fixing points.
- ▶ Calculate and observe the permitted payload for the mounted or towed implement.
- ▶ Observe the permissible axle loads and drawbar loads of the tractor.
- ▶ Observe the permissible drawbar load of the hitch device and drawbar.
- ▶ Comply with the permissible transport width and transport height of the implement.
- ▶ Drive in such a way that you always have full control over the tractor with the mounted or towed implement. In so doing, take your personal abilities into account, as well as the road, traffic, visibility and weather conditions, the driving characteristics of the tractor, and the influence of the mounted implement.

#### **When driving on roads, risk of accident caused by uncontrolled lateral motions of the implement**

- ▶ Lock the tractor lower links for road travel.

#### **Preparing the implement for road travel**

If the machine is not properly prepared for road travel, it can result in serious traffic accidents.

- ▶ Check the lighting and identification for road travel for proper function.
- ▶ Remove coarse dirt from the implement.
- ▶ Use the warning beacon in compliance with the national regulations.
- ▶ Switch off the work lights.
- ▶ Lock the tractor control units.
- ▶ Follow the instructions in the section "Preparing the implement for road travel".

### Parking the implement

The parked machine can tip over. People can be crushed and killed.

- ▶ Only park the machine on stable and even ground.
- ▶ *Before you perform setting or maintenance work,* make sure that the implement is in a stable position. In case of doubt, support the implement.
- ▶ Follow the instructions in the section "*Parking the implement*".

### Unsupervised parking

Parked tractors with coupled implements that are insufficiently secured and unsupervised represent danger for people and playing children.

- ▶ *Before you leave the machine,* shutdown the tractor and the implement.
- ▶ Secure the tractor and machine.

### Do not use the control computer or control terminal during road travel

If the driver is distracted, it can result in accidents and injuries or even death.

- ▶ Do not operate the control computer or control terminal during road travel.

## 2.1.4 Safe maintenance and modification

CMS-T-00002305-M.1

### 2.1.4.1 Changes on the implement

CMS-T-00002322-B.1

#### Only authorised design changes

Design changes and extensions can impede the functioning and operational safety of the machine. This can result in serious injury or death.

- ▶ Have any design changes and extensions performed only by a qualified specialist workshop.
- ▶ *To ensure that the operating permit remains valid in accordance with national and international regulations,* ensure that the specialist workshop only uses conversion parts, spare parts and special equipment approved by AMAZONE.

#### 2.1.4.2 Work on the machine

CMS-T-00002323-L.1

##### **Only work on the machine when it is at a standstill**

If the machine is not standing still, part can move unintentionally or the machine can be set in motion. This can result in serious injury or death.

- ▶ *If you have to work on or under raised loads:*  
Lower the loads or secure the loads with a hydraulic or mechanical locking device.
- ▶ Switch off all drives.
- ▶ Actuate the parking brake.
- ▶ Particularly on slopes, additionally secure the machine against rolling away with wheel chocks.
- ▶ Remove the ignition key and carry it with you.
- ▶ Wait until all parts that are still running come to a stop and until hot parts cool down.
- ▶ Do not stand on moving parts.

### Maintenance work

Improper maintenance work, particularly on safety-related components, endangers operational safety. This can result in accidents and serious personal injury or even death. Safety-related components include, for example, hydraulic components, electronic components, frames, springs, trailer coupling, axles and axle suspensions, lines and tanks containing flammable substances.

- ▶ *Before you adjust, maintain or clean the machine,* secure the machine.
  
- ▶ Repair the machine according to this operating manual.
  
- ▶ Only perform the work that is described in this operating manual.
  
- ▶ Have maintenance work that is labelled as "WORKSHOP WORK" performed at a workshop that is adequately equipped in terms of agricultural technology, safety and environmental technology by specialist personnel with appropriate training.
  
- ▶ Never perform welding, drilling, sawing, grinding, and cutting work on the frame, running gear or coupling devices of the implement.
  
- ▶ Never modify safety-related components.
  
- ▶ Never drill out existing holes.
  
- ▶ Perform all maintenance work at the prescribed maintenance intervals.



CMS-I-00007119

### Raised implement parts

Raised implement parts can descend unintentionally and crush or kill people.

- ▶ Never linger under raised implement parts.
- ▶ *If you have to work on or under raised machine parts,*  
lower the implement parts or secure the raised implement parts with a mechanical support or hydraulic locking device.

### Danger due to welding work

Improper welding work, particularly on or close to safety-related components, endangers the operational safety of the implement. This can result in accidents and serious personal injury or even death. Safety-related components include, for example, hydraulic components and electronic components, frames, springs, coupling devices to the tractor such as the three-point mounting frame, drawbar, trailer support, trailer coupling or tensioned crosspiece as well as axles and axle suspensions, lines and tanks containing flammable substances.

- ▶ Allow only qualified specialist workshops with suitably approved personnel to perform welding work on safety-related components.
- ▶ Only allow qualified personnel to perform welding work on all other components.
- ▶ *If you have doubts as to whether a component can be welded:*  
Ask a qualified specialist workshop.
- ▶ *Before welding on the implement:*  
Uncouple the implement from the tractor.
- ▶ Do not weld close to a field sprayer that was previously used to spread liquid fertiliser.

#### 2.1.4.3 Operating materials

CMS-T-00002324-C.1

### Unsuitable operating materials

Operating materials that do not meet AMAZONE requirements can cause implement damage and accidents.

- ▶ Only use operating material that meet the requirements in the Technical Data.

#### 2.1.4.4 Special equipment and spare parts

CMS-T-00002325-B.1

##### Special equipment, accessories, and spare parts

Special equipment, accessories, and spare parts that do not meet AMAZONE requirements can impede the operational safety of the implement and cause accidents.

- ▶ Only use original parts or parts that meet AMAZONE requirements.
- ▶ *If you have any questions regarding special equipment, accessories or spare parts, contact your dealer or AMAZONE.*

## 2.2 Safety routines

CMS-T-00002300-E.1

##### Securing the tractor and implement

If the tractor and implement are not secured against unintentional starting and rolling away, the tractor and implement can be set in motion in an uncontrolled manner, and can run over, crush and kill people.

- ▶ Lower the raised implement or raised implement parts.
- ▶ Relieve pressure in the hydraulic hose lines by actuating the operating devices.
- ▶ *If you have to stand under the raised implement or components, secure the raised implement and components against lowering with a mechanical safety support or hydraulic locking device.*
- ▶ Switch off the tractor.
- ▶ Apply the tractor's parking brake.
- ▶ Remove the ignition key.

##### Securing the machine

After uncoupling, the implement has to be secured. If the implement and implement parts are not secured, there is a risk of personal injury due to crushing and cutting.

- ▶ Only park the implement on stable and level ground.
- ▶ *Before you depressurise the hydraulic hose lines and disconnect them from the tractor, move the implement into working position.*
- ▶ Protect people against direct contact with sharp-edged or protruding implement parts.

### **Make sure that the protective equipment is functional**

If protective equipment is missing, damaged or removed, implement parts can cause serious personal injury or even death.

- ▶ Before beginning work, check whether the protective devices have been deactivated or manipulated.
- ▶ Check the implement at least once a day for damage, proper installation, and functioning of the protective equipment.
- ▶ *If you are not sure if the protective equipment is properly installed and functional:*  
Have the protective equipment checked by a qualified specialist workshop.
- ▶ Make sure that the protective devices are properly installed and functional before any work on the implement.
- ▶ Replace damaged protective equipment.

### **Climbing on and off**

Negligent behaviour while climbing on and off can cause people to fall off the ladder. People who climb onto the implement without using the intended access steps can slip, fall, and suffer severe injury. Dirt and operating materials can impair stepping and standing safety. Accidental actuation of control elements can unintentionally activate potentially dangerous functions.

- ▶ Use only the intended access steps.
- ▶ *To ensure safe stepping and standing:*  
Always keep steps and platforms clean and in proper condition.
- ▶ *When the implement is moving:*  
Never climb onto or off of the implement.
- ▶ Climb up and down facing the implement.
- ▶ When climbing up and down, maintain contact with at least 3 points on the steps and handrails: always keep 2 hands and one foot or 2 feet and one hand on the implement.
- ▶ When climbing up and down, never hold onto the control elements.
- ▶ When climbing down, never jump off of the implement.

## Intended use

# 3

CMS-T-00005043-B.1

- The implement is intended solely for professional use for soil tillage on agricultural crop lands according to Good Agricultural Practices.
- The implement is an agricultural implement to be mounted on the three-point power lift of a tractor that meets the technical requirements.
- The implement is suitable and intended for shallow stubble cultivation or breaking up fallow land, for seedbed preparation and incorporating catch crops or farm manure.
- The soil tillage implement may only be used with the rollers specified in the operating manual.
- When driving on public roads, the implement, depending on the provisions of the applicable road traffic regulations, can be mounted and transported at the rear of a tractor that meets the technical requirements.
- The implement may only be used and maintained by persons who fulfil the requirements. The personnel requirements are described in the section "*Personnel qualification*".
- The operating manual is part of the implement. The implement is solely intended for use in compliance with this operating manual. Uses of the implement that are not described in this operating manual can lead to serious personal injuries or even death and to implement and material damage.
- The applicable accident prevention regulations as well as generally accepted safety-related, occupational health and road traffic regulations must also be observed by the users and the owner.
- Further instructions for intended use in special cases can be requested from AMAZONE.
- Uses other than those specified under the intended use are considered as improper. The manufacturer is not liable for any damage resulting from improper use, solely the operator is responsible.


# Product description

# 4

CMS-T-00010013-E.1


## 4.1 Implement overview

CMS-T-00010018-B.1



CMS-I-00006818

- |  |  |
|--|--|
| <b>1</b> Side guide plate              | <b>2</b> Tines                                       |
| <b>3</b> Interchangeable wheel gear    | <b>4</b> Lighting and identification for road travel |
| <b>5</b> Hose cabinet                  | <b>6</b> Three-point mounting frame                  |
| <b>7</b> Universal joint shaft         | <b>8</b> Front tool protection                       |
| <b>9</b> Rating plate on the implement | <b>10</b> Universal joint shaft bracket              |
| <b>11</b> Frame transport lock         | <b>11</b> Operating tool                             |
| <b>13</b> Working depth adjustment     |  |




CMS-I-00006817

- |  |   |
|--|---|
| <b>1</b> Lighting and identification for road travel | <b>2</b> Scraper                                  |
| <b>3</b> Roller                                      | <b>4</b> Centre gearbox                           |
| <b>5</b> Threaded cartridge                          | <b>6</b> Levelling board working depth adjustment |
| <b>7</b> Universal operating tool                    |   |

## 4.2 Function of the implement


CMS-T-00004656-C.1

The tines **4** break open the soil. Organic residues **5** are intensively incorporated. The levelling board **3** levels the flow of soil between the tool tines and the roller **1**. To crush large clods of soil more effectively, the soil clods are held between the tool tines by the levelling board. The roller reconsolidates the soil and produces the finished seedbed **2**.



CMS-I-00002954

The tines **2** are fastened to the sockets **1** of the tool carrier. The sockets are shaped in such a way that the tines have a spring action and can deflect on rocks and other obstacles.



CMS-I-00002948

For operation as a seeding combination, the soil tillage implement can be combined with a pack top seed drill.

### 4.3 Special equipment

CMS-T-00010139-A.1

- Centre line eradicator
- Lighting and identification for road travel
- Gear wheel change set 31/40 teeth
- Rollers


### 4.4 Protective equipment

CMS-T-00010014-B.1

#### 4.4.1 Universal joint shaft guard

CMS-T-00003992-D.1

As standard, the universal joint shafts are equipped with guard tubes **2** and guard cones **1**. Depending on the implement equipment, holding chains or full guard cones fix the guard tubes. This rules out the risk of winding.




CMS-I-00002930

### 4.4.2 Tool protection


The tool guard prevents sand clods or stones from being thrown up and out of the implement. It also prevents accidental touching. The tool guard consists of the side guide plates **1** and the protective panels **2**.

CMS-T-00003994-C.1



CMS-I-00003296

Towards the rear, the tool guard contains a guard tube **1** and trailing roller **2**.




CMS-I-00003297

### 4.4.3 Frame transport lock

The transport lock **1** prevents the folding frame parts **2** from unfolding unintentionally. The transport lock is unlocked hydraulically.

CMS-T-00010015-B.1




CMS-I-00006827

#### 4.4.4 Roller transport lock

The transport lock **1** prevents the carrying arms **2** from swinging excessively with the trailing roller in the folded state.

CMS-T-00010016-B.1




CMS-I-00006828

### 4.5 Warning symbols


CMS-T-00010019-E.1

#### 4.5.1 Positions of the warning symbols

CMS-T-00010020-B.1



CMS-I-00006920



CMS-I-00006921


#### 4.5.2 Layout of the warning symbols

CMS-T-000141-D.1

Warning symbols indicate danger areas on the machine and warn against residual dangers. In these danger areas, there are permanent or unexpected dangers.

A warning symbol consists of two fields:

- Field **1** shows the following:
  - A pictogram depicting the danger area, surrounded by triangular safety symbol
  - The order number
- Field **2** shows a pictogram depicting how to avoid the danger.



CMS-I-00000416

### 4.5.3 Description of the warning symbols

CMS-T-00010021-E.1

#### MD 075

##### Risk of cuts for fingers, hands, and arms

- ▶ Disconnect the power supply from the implement before approaching the danger zone.
- ▶ Wait until all moving parts are at a standstill before reaching into the danger area.
- ▶ Make sure that there is nobody standing in the danger area or close to the moving parts.



CMS-I-00000418

#### MD 078

##### Risk of crushing fingers or hands

- ▶ Disconnect the power supply from the implement before approaching the danger zone.
- ▶ Wait until all moving parts are at a standstill before reaching into the danger area.
- ▶ Make sure that there is nobody standing in the danger area or close to the moving parts.



CMS-I-0000074

#### MD 079

##### Danger due to ejected material

- ▶ Make sure that there is nobody standing in the danger area or close to the moving parts.



CMS-I-0000076

#### MD 082

##### Risk of falling from tread surfaces and platforms

- ▶ Do not let anybody ride on the implement.
- ▶ Do not let anybody climb onto the driving implement.




CMS-I-0000081

**MD 087**

**Danger due to cutting and moving machine parts**

- ▶ Disconnect the power supply from the implement before approaching the danger zone.
- ▶ Wait until all moving parts are at a standstill before entering the danger area.
- ▶ Make sure that there is nobody standing in the danger area or close to the moving parts.




CMS-I-000691

**MD094**

**Danger due to transmission lines**

- ▶ Never touch transmission lines with the implement.
- ▶ Maintain an adequately safe distance from electrical transmission lines, especially when folding or unfolding implement parts.
- ▶ Please note that the voltage can flash over when the distance is too small.



CMS-I-000692

**MD095**

**Risk of accident due to non-compliance with the instructions in this operating manual**

- ▶ Before your work on or with the implement, read and understand the operating manual.




CMS-I-000138

### MD 096

#### Risk of infection from escaping hydraulic fluid under high pressure

- ▶ Have the hydraulic system checked and repaired by a qualified specialist workshop only.
- ▶ Stay away from leaks in the hydraulic system.
- ▶ *If you are injured by hydraulic oil, consult a doctor immediately.*



CMS-I-000216

### MD 097

#### Risk of crushing between the tractor and the implement

- ▶ *Before you actuate the tractor hydraulic system, instruct persons away from the area between the tractor and the implement.*
- ▶ Actuate the tractor hydraulic system only from the designated work station.




CMS-I-000139

### MD 100

#### Risk of accidents due to improperly attached lifting gear

- ▶ Only attach the lifting gear at the marked positions.



CMS-I-000089

**MD 102**

**Danger due to unintentional starting as well as unintentional and uncontrolled movements of the implement**

- ▶ Before all tasks, secure the implement against unintentional starting as well as unintentional and uncontrolled movements.




CMS-I-00002253

**MD119**

**Risk of implement damage due to excessively high drive speeds and incorrect direction of rotation of the drive shaft**

- ▶ Comply with the maximum drive speed and direction of rotation of the drive shaft on the implement side, as shown on the pictogram.




CMS-I-00003656

**MD 155**

**Risk of accident and machine damage during transport due to improperly secured machine**

- ▶ Only attach the lashing belts at the marked lashing positions for transporting the machine.




CMS-I-00000450

### MD 199

**Risk of accident if the hydraulic system pressure is too high**

- ▶ Only couple the implement to tractors with a maximum tractor hydraulic pressure of 210 bar.



### MD 273

**Risk of crushing for the whole body from lowering implement parts**

- ▶ Make sure that there is nobody standing in the danger area.



## 4.6 Threaded cartridge

CMS-T-00001776-F.1


The threaded cartridge contains documents and, depending on the implement equipment, other aids.



## 4.7 Three-point mounting frame

CMS-T-00010017-B.1

- 1 Category 3 lower link mounting
- 2 Spacer discs for the ball sleeves
- 3 Category 3 top link mounting
- 4 Additional Category 3 top link mounting




CMS-I-00006825

The three-point mounting frame is used to couple the implement onto the tractor. The three-point mounting frame can be adjusted to the three-point power lift with spacer discs.

## 4.8 Rating plate on the implement

CMS-T-00004505-L.1


- 1 Serial number
- 2 Vehicle ID number
- 3 Product
- 4 Permissible technical implement weight
- 5 Model year
- 6 Year of manufacture



## 4.9 Universal operating tool

CMS-T-00001735-C.1

Setting work on the implement is performed with the universal operating tool **1**. The universal operating tool is parked in a holder on the implement frame.




CMS-I-00001082

## 4.10 Universal joint shaft locking mechanism

CMS-T-00005052-A.1

If the tool carriers encounter an obstacle, the tool carriers can be blocked.

Depending on the implement equipment, the ratchet clutches **1** or shear bolts on the universal joint shafts prevent damage to the gearboxes.



CMS-I-00003044

## 4.11 Lighting and identification for road travel


CMS-T-00009982-C.1

### 4.11.1 Rear lighting and identification for road travel

CMS-T-00001498-G.1

The equipment can vary depending on the implement type or country-specific regulations.

- 1 Red reflectors, triangular on trailed implements or non-triangular on mounted implements
- 2 Rear lights, brake lights, and turn indicators
- 3 Yellow reflectors
- 4 Warning sign
- 5 Orange fluorescent warning sticker for implement width > 3.6 m
- 6 Red reflecting warning sticker
- 7 Yellow reflecting warning sticker
- 8 Identification panel for slow-driving vehicles




### 4.11.2 Front lighting and identification for road travel

CMS-T-00006393-C.1

The equipment can vary depending on the implement type or country-specific regulations.


- 1 Marker light
- 2 White reflectors
- 3 Warning sign
- 4 Turn indicator for implement width > 3.6 m
- 5 Yellow reflecting warning sticker



### 4.11.3 Additional license plate

CMS-T-00003999-C.1

- 1 Licence plate lighting
- 2 Licence plate holder



CMS-I-00003163

## 4.12 Rollers

CMS-T-00010410-C.1

### 4.12.1 AMAZONE rollers

CMS-T-00010149-B.1

Rollers are used to maintain the working depth, to reconsolidate the soil, and to protect against the rotating tools of the soil tillage implement.

#### **i** NOTE

In combination with a seed drill, the soil tillage implement may only be used with the rollers specified in the seed drill operating manual.

Roller	Working width	
	4.5 m	6 m
Tooth packer roller	PW 2000-600 PW 2500-600	2x PW 3000-600
Wedge ring roller	KW 2000-580 KW 2500-580	2x KW 3000-580
Wedge ring roller with matrix tyres	KWM 2000-600 KWM 2500-600	2x KWM 3000-600

#### 4 | Product description

##### Rollers

Roller	Working width	
	4.5 m	6 m
Trapeze ring roller	TRW 2000-500	2x TRW 3000-500
	TRW 2500-500	
	TRW 2000-600	2x TRW 3000-600
	TRW 2500-600	

#### 4.12.2 Packer rollers from other manufacturers

CMS-T-00010409-B.1

The AMAZONE roller product range is supplemented with rollers from third-party suppliers.

Packer rollers from other manufacturers	Working width 4 m	Working width 5 m	Working width 6 m	Roller frame
Güttler Simplex prismatic roller with spheroidal graphite iron rings	-	2x 2500-SX-45 SG	2x 3000-SX-45 SG	1-tube roller frame
Güttler Simplex prismatic roller with synthetic ultra rings	-	2x 2500-SX-45 SU	2x 3000-SX-45 SU	
	-	2x 2500-SX-50 SU	2x 3000-SX-50 SU	2-tube roller frame
	-	2x 2500-SX-56 SU	2x 3000-SX-56 SU	

## Technical data

5

CMS-T-00010038-D.1

### 5.1 Dimensions

CMS-T-00010040-A.1

Dimensions	KE 6002-2
Transport width	3000 mm
Transport height	3600 mm
Total length	2200 mm
Working width	6044 mm
Centre of gravity distance with roller	710 mm

### 5.2 Permissible total weight

CMS-T-00010044-A.1

KE 6002-2
4400 kg

### 5.3 Mounting category

CMS-T-00010039-A.1

Type	Operation	Mounting category
KE 6002-2	Solo operation	Category 3/4N

### 5.4 Forward speed

CMS-T-00010042-B.1

Optimal working speed	4-12 km/h
Permissible transport speed	40 km/h

## 5.5 Working depth

CMS-T-00004661-B.1

Tines	Length of the tines	Maximum working depth
Trailing tines	29.3 cm	20 cm

## 5.6 Performance characteristics of the tractor

CMS-T-00010043-A.1

Use as a solo implement	Engine rating
KE 6002-2	Up to 294 kW / 400 HP

Electrical system	
Battery voltage	12 V
Lighting socket	7-pin, in accordance with ISO 1724

Hydraulic system	
Maximum operating pressure	210 bar
Tractor pump output	Depending on the implement equipment, 30 l/min at 180 bar
Implement hydraulic oil	HLP68 DIN51524 The hydraulic oil is suitable for the combined hydraulic oil circuits of all standard tractor manufacturers.
Control units	1x double-acting
Universal joint shaft	
Speed	1000 rpm
Direction of rotation	Clockwise

## 5.7 Noise development data

CMS-T-00004666-A.1

The workplace-related emission sound pressure level is lower than 72 dB(A), measured in operating condition at the ear of the tractor driver with the cab closed.

The emission sound pressure level is primarily dependent on the vehicle used.

## 5.8 Drivable slope inclination

CMS-T-00002297-E.1

Across the slope		
On left in direction of travel	15 %	
On right in direction of travel	15 %	

Up the slope and down the slope		
Up the slope	15 %	
Down the slope	15 %	

## 5.9 Lubricants

CMS-T-00002396-B.1

Manufacturer	Lubricant
ARAL	Aralub HL2
FINA	Marson L2
ESSO	Beacon 2
SHELL	Retinax A

## 5.10 Oils and filling capacities

CMS-T-00010041-C.1

### NOTE

Oils with SAE 80W90 – API GL5 specifications can be topped up or replace the existing oil in the interchangeable wheel gear.

Specifications for the centre gearbox and the interchangeable wheel gears:

Implement	Gearbox	Factory filling	Fill quantity
KE 6002-2-400	Centre gearbox	Factory filling: Mobil SHC 632	Without oil cooler: 7.2 litres
		Addinol ECO Gear S 320 Addinol CKT gear oil 320 Shell Omala S4 GXV 320	
	Interchangeable wheel gear	Factory filling: Mobil ISO VG SAE 80W-90 API GL5	With oil cooler: -

**NOTE**

Specifications for the spur gear trough:

Oils that comply with the standard CLP/CKC 460 DIN 51517 Part 3 / ISO 12925 can be topped up or used to replace the existing oil in the spur gear trough.

The following table contains several gear oil types that comply with the standard.

Manufacturer	Gear oil
Wintershall	Factory filling: ERSOLAN 460
Agip	Blasia 460
ARAL	Degol BG 460
Autol	Precis GEP 460
Avia	Avilub RSX 460
BP	Energol GR-XP 460
Castrol	Alpha SP 460
DEA	Falcon CLP 460
ESSO	Spartan EP 460
FINA	Giran 460
Fuchs	Renep Compound 110
Mobil	Mobilgear 600 XP 460
Shell	Omala 460
OMV	OMV Gear HST 460

Implement type	Filling quantity for each spur gear trough
KE 6002-2	16 litres

## 5.11 Permissible payload

CMS-T-00011018-E.1

Permissible payload for operation
Permissible payload = $G_z - G_L =$ _____ kg

- $G_z$ : Permissible technical implement weight according to the rating plate [ kg]
- $G_L$ : Determined tare weight [ kg]


# Preparing the machine

# 6

CMS-T-00010027-E.1

## 6.1 Calculating the required tractor characteristics

CMS-T-00000063-F.1



CMS-I-00000581

Designation	Unit	Description	Calculated values
$T_L$	kg	Tractor empty weight	
$T_V$	kg	Front axle load of the operational tractor without mounted implement or ballast weights	
$T_H$	kg	Rear axle load of the operational tractor without mounted implement or ballast weights	
$G_V$	kg	Total weight of front-mounted implement or front ballast	
$G_H$	kg	Permissible total weight of rear-mounted implement or rear ballast	
$a$	m	Distance between the centre of gravity of the front-mounted implement or the front ballast and the centre of the front axle	

Designation	Unit	Description	Calculated values
a <sub>1</sub>	m	Distance between the centre of the front axle and the centre of the lower link connection	
a <sub>2</sub>	m	Centre of gravity distance: Distance between the centre of gravity of the front-mounted implement or the front ballast and the centre of the lower link connection	
b	m	Wheelbase	
c	m	Distance between the centre of the rear axle and the centre of the lower link connection	
d	m	Centre of gravity distance: Distance between the centre of the lower link coupling point and centre of gravity of the rear-mounted implement or rear ballast.	

1. Calculate the minimum front ballasting.

$$G_{\min} = \frac{G_H \cdot (c + d) - T_V \cdot b + 0,2 \cdot T_L \cdot b}{a + b}$$

$$G_{\min} = \underline{\hspace{10em}}$$

$$G_{\min} = \text{[Grey box]}$$

CMS-I-00000513

2. Calculate the actual front axle load.

$$T_{\text{Vtat}} = \frac{G_V \cdot (a + b) + T_V \cdot b - G_H \cdot (c + d)}{b}$$

$$T_{\text{Vtat}} = \underline{\hspace{10em}}$$

$$T_{\text{Vtat}} = \text{[Grey box]}$$

CMS-I-00000516

**6 | Preparing the machine**  
**Calculating the required tractor characteristics**

3. Calculate the actual total weight of the tractor-implement combination.

$$G_{tat} = G_V + T_L + G_H$$

$$G_{tat} =$$

$$G_{tat} =$$

CMS-I-00000515

4. Calculate the actual rear axle load.

$$T_{Htat} = G_{tat} - T_{Vtat}$$

$$T_{Htat} =$$

$$T_{Htat} =$$

CMS-I-00000514

5. Determine the tyre load capacity for two tractor tyres in the manufacturer specifications.
6. Write down the determined values in the following table.



**IMPORTANT**

**Danger of accident due to implement damage caused by excessive loads**

- Make sure that the calculated loads are smaller or equal to the permissible loads.

	Actual value according to calculation			Permitted value according to tractor operating manual			Tyre load capacity for two tractor tyres	
Minimum front ballasting		kg	≤		kg		-	-
Total weight		kg	≤		kg		-	-
Front axle load		kg	≤		kg	≤		kg
Rear axle load		kg	≤		kg	≤		kg


## 6.2 Attaching the backstop profiles for the lower links

CMS-T-00004040-E.1

The three-point mounting frame is adjusted to the catch hooks of the tractor using the spacer discs **2**.

### **i** NOTE

The ball sleeves **1** can only be used with Cat. 3 pins **3**.



CMS-I-00003055

Lower link catch hook	Spacer discs
Category 3	t=13.5 mm
Category 4N	t=6.5 mm

Top link catch hook	Spacer discs
Category 3	t=6.5 mm
Category 4N	Without spacer disc

1. Determine the spacer discs according to the catch hooks on the tractor.
2. Install the ball sleeves and spacer discs.

## 6 Preparing the universal joint shaft

CMS-T-00015288-A.1



### WORKSHOP WORK

1. Adjust the length of the universal joint shaft.
2. Install the universal joint shaft.

### 6.3 Installing the universal joint shaft on the implement


CMS-T-00010034-B.1



#### IMPORTANT

**Damage when the universal joint shaft is too long**

- ▶ *To avoid damage to the implement, check the universal joint shaft length every time the tractor is changed.*
- ▶ *If the universal joint shaft is too long, have the universal joint shaft corrected by a qualified specialist workshop.*



CMS-I-00006826

1. Clean and grease the drive shaft on the implement.
2. Make sure that the universal joint shaft guard is functional.

The tractor symbol on the guard tube identifies the tractor-side of the universal joint shaft. An existing overload clutch or freewheel clutch must be installed on the implement side.

3. Slide the universal joint shaft **1** onto the gearbox output shaft **3**.
4. *To secure the universal joint shaft on the gearbox,* tighten the locking bolt on the universal joint shaft with the tightening torque prescribed by the universal joint shaft manufacturer.
5. Lift the bracket **2** out of the holder.
6. Swivel the bracket under the universal joint shaft.
7. Put the universal joint shaft in the bracket.
8. Secure the guard tube with the safety chain on the fastening point **4**.

## 6.4 Coupling the implement


CMS-T-00010030-D.1

### 6.4.1 Driving the tractor towards the implement

CMS-T-00005794-D.1

Enough space must remain between the tractor and implement so that the supply lines can be coupled without obstructions.

- ▶ Drive the tractor towards the implement, leaving a sufficient distance.



CMS-I-00004045

### 6.4.2 Coupling the three-point extension

CMS-T-00019123-A.1

For operation with wheel mark eradicators, the three-point extension **1** is required. Due to the greater distance from the tractor, a longer universal joint shaft is required.


#### **i** NOTE

Using a three-point extension for operation of a seeding combination is not permitted.

1. Couple the three-point extension onto the three-point mounting frame **2** on the tractor.

For the KG01 product type, the 132 mm top link lever is required. For the KG02 or KE02 product type, the 104 mm top link lever is required.


2. Couple the soil tillage implement onto the three-point extension.



### 6.4.3 Coupling the three-point mounting frame

CMS-T-00001400-H.1

1. Set the lower link **1** at the same height.
2. Couple the lower links from the tractor seat.
3. Couple the top link **2**.
4. Check whether the top link catch hooks **3** and lower link catch hooks **4** are correctly locked.




CMS-I-00001225

### 6.4.4 Coupling the hydraulic hose lines

CMS-T-00010085-C.1

All hydraulic hoses are equipped with handles. The handles have colour markings with a code number or a code letter. The markings are assigned to the respective hydraulic functions of the pressure line of a tractor control unit. Stickers are applied on the implement for the markings, which illustrate the respective hydraulic functions.

The tractor control unit is used with different types of actuation, depending on the hydraulic function:



CMS-I-00000121

Type of actuation	Function	Symbol
Latching	Permanent oil circulation	
Momentary	Oil circulation until action is executed	
Floating	Free oil flow in the tractor control unit	


Designation		Function		Tractor control unit	
Green	<b>1</b>		Folding the implement	Unfold	Double-acting
	<b>2</b>			Fold	



## IMPORTANT

### Implement damage due to insufficient hydraulic oil return flow

- ▶ On the tractor side, only use lines that correspond to the nominal width of "red T" of the implement or larger for the pressureless hydraulic oil return flow.
- ▶ Select short return paths.
- ▶ Connect the pressureless hydraulic oil return flow to the intended coupling before all of the other hydraulic connections.
- ▶ *If the implement has a leakage oil line:* couple the leakage oil line in the intended coupling.
- ▶ Install the supplied coupling sleeve on the pressureless hydraulic oil return.



CMS-I-00001045

1. Depressurise the hydraulic system between the tractor and the implement using the tractor control unit.
2. Clean the hydraulic plugs.




## NOTE

If the hydraulic hose lines are incorrectly connected, the hydraulic functions may be faulty.

3. Couple the hydraulic hose lines **1** to the hydraulic sockets of the tractor according to the label **2**.
- ➔ The hydraulic plugs lock perceptibly.
4. Route the hydraulic hose lines with sufficient freedom of movement and without chafing points.

### 6.4.5 Coupling the lighting for road travel

1. Insert the plug **1** for the lighting.
2. Route the cable with sufficient freedom of movement and without chafing or pinching points.
3. Check the lighting on the implement for proper function.




CMS-T-00001399-H.1

CMS-I-00001048

### 6.4.6 Coupling the universal joint shaft

1. Take the universal joint shaft out of its holder on the implement.
  2. Pull back the drawing sleeve **1** on the tractor side.
  3. Push the universal joint shaft onto the tractor PTO shaft.
- ➔ The drawing sleeve engages.
4. *To secure the universal joint shaft guard against rotating:*  
Fasten the safety chain **2** onto the tractor.
  5. Check the guard on the universal joint shaft.



CMS-T-00012829-B.1

CMS-I-00001069

### 6.4.7 Calculating the permissible payload



#### **WARNING**

#### **Risk of accident due to exceeded payload**

If the payload is exceeded, the implement can be damaged or/and it can result in uncontrolled driving behaviour of the tractor.

- ▶ Carefully determine the payload of the implement.
- ▶ Never exceed the payload of the implement.

CMS-T-00002254-D.1

Maximum payload = Permissible technical implement weight - tare weight

1. Read the permissible technical implement weight from the rating plate.
2. *To determine the tare weight,* weigh the implement with empty hoppers.
3. Calculate the payload.

## 6.5 Preparing the implement for operation

CMS-T-00010032-B.1

### 6.5.1 Manual adjustment of the tine working depth


CMS-T-00010045-B.1

The soil tillage implement **2** is supported by the carrying arms of the trailing roller **1**. To adjust the working depth, the depth setting pin **3** is inserted in the desired hole.



CMS-I-00003428

1. Raise the implement.  
➔ The pins **2** are no longer resting on the carrying arms **1**.
2. Secure the tractor and implement.
3. Remove the linch pin **3**.




CMS-I-00003426

Pegging position	Working depth
Higher <b>+</b>	Deep tillage
Lower <b>-</b>	Shallow tillage

**i** NOTE

The adjustment of the working depth must be adapted to the respective operating conditions. The optimum adjustment can only be determined during field operation.

4. Put the pins in the desired position.
5. Secure the pin with the linch pin.
6. Remove the linch pin **1**.
7. Put the pins **3** on the adjusting rod **2** in the desired position.
8. Rest the adjusting rod in the support.
9. Secure the pin with the linch pin.
10. Make the same setting for the opposite side of the implement.




CMS-I-00006829

### 6.5.2 Adjusting the working height of the levelling board


CMS-T-00004620-D.1

The levelling board **1** levels the flow of soil between the tines and the roller. To crush large clods of soil more effectively, the soil clods are held between the tines by the levelling board. The levelling board can deflect upwards thanks to the integrated overload safety. The working height of the levelling board can be adjusted.



CMS-I-00002945

1. Insert the universal operating tool **1** in the adjustment device **2**.
2. *To relieve the locking mechanism **4**:* swivel the adjustment device slightly upwards.
3. Release the locking mechanism. Hold the universal operating tool in position.
4. *For conventional seeding:*  
Reduce **-** the working height of the levelling board **3**.



CMS-I-00003454

- ➔ The locking mechanism must engage.
  - ➔ The levelling board is pushing up a small ridge of soil.
5. *For mulch seeding:*  
Increase the working height of the levelling board **+**.
- ➔ The locking mechanism must engage.
  - ➔ Crop residues are able to pass under the levelling board.
6. Make the same setting for the opposite side of the implement.
  7. *To check the setting:*  
Drive for 30 m at working speed. Check the work pattern.

### 6.5.3 Adjusting the working depth of the side guide plates

CMS-T-00010046-A.1


The side guide plate ensures that the tilled soil is not thrown to the side. The working depth can be adjusted. The soil guiding angle bracket additionally prevents free-flowing soil from escaping.

## 6 | Preparing the machine

### Preparing the implement for operation

1. Loosen the bolts **1**.

Work application	Working depth
After the plough	<b>-</b> The side guide plates glide through the soil at a depth of 1 to 2 cm
For mulch seeding with coarse organic residues	<b>+</b> Install the side guide plates slightly higher at the front to allow crop residues to pass underneath.



CMS-I-00003448

#### **i** NOTE

The adjustment of the working depth must be adapted to the respective operating conditions. The optimum adjustment can only be determined during field operation.

2. *To release the side guide plate from the grid,* push the side guide plate towards the front.
3. Move the side guide plate to the desired position.
4. Push the side guide plate into the grid.
5. Tighten the bolts.
6. Make the same setting for the opposite side of the implement.
7. *To check the setting,* seed for approx. 30 m at working speed and then check the work pattern.

The soil guiding angle brackets may not work too deep. The soil guiding angle brackets may only level the soil ridge between the side guide plate and the trailing roller.

8. Loosen the bolts.
9. Move the soil guiding angle bracket **2** to the desired position.
10. Tighten the bolts.
11. Make the same setting for the opposite side of the implement.
12. *To check the setting,* seed for approx. 30 m at working speed and then check the work pattern.


### 6.5.4 Adjusting the spring tension of the side guide plates

CMS-T-00010047-A.1

The swivelling side panel deflects upwards on obstacles. The dead weight of the side panel and a tension spring bring the side panel back into working position. The pre-tensioning of the tension spring is adjustable.

The tension of the spring for the side guide plates **1** has been adjusted at the factory for light and medium soils.

Work application	Spring tension
After the plough, heavy soils	Increase <b>+</b>
After the plough, light soils	Reduce <b>-</b>
For mulch seeding with coarse organic residues	Reduce <b>-</b> To allow crop residues to pass underneath the side guide plates.



CMS-I-00003451

#### **i** NOTE


The adjustment of the working depth must be adapted to the respective operating conditions. The optimum adjustment can only be determined during field operation.

1. To move the spring tension **3** to the desired position, adjust the preload with the nut **2**.
2. Make the same setting for the opposite side of the implement.
3. To check the setting, seed for approx. 30 m at working speed and then check the work pattern.

### 6.5.5 Adjusting the speed of the tines


CMS-T-00010160-B.1

1. Depending on the desired tine speed **2**:  
determine the required gear ratio **1**.



CMS-I-00003483

2. Park the soil tillage implement on a firm surface.
3. To prevent oil from emerging out of the interchangeable wheel gears: slightly fold the soil tillage implement. Support with suitable aids.
4. Remove the peripheral cover screws **1**.




CMS-I-00003397

**ENVIRONMENTAL INFORMATION** Danger due to escaping oil


- ▶ Collect any escaping oil.
- ▶ Dispose of oil removal material in an environmentally friendly manner.

5. Remove the gearbox cover **2**.
6. Remove both locking rings **2**.
7. Remove the gear pair.
8. Install the determined gear pair on the drive shaft **3** and the output shaft **1**.
9. Install the two locking rings.
10. Check the seating of the sealing ring on the gearbox cover.



CMS-I-00003398


11. Install the gearbox cover **2** with the sealing ring.
12. Install and tighten the peripheral cover screws **1**.
13. Set the same gear ratio for the opposite side of the implement.
14. *After 15 minutes of operation:* check the gearbox for leaks.



CMS-I-00003480

### 6.5.6 Using the centre line eradicator

The centre line eradicator **1** levels the tillage horizon between the implement sections. This prevents the formation of a centre soil ridge.



CMS-T-00004047-C.1

CMS-I-00002944

#### REQUIREMENTS


- ☉ The implement is not coupled.

#### NOTE

Install the centre line eradicator only if the soil tillage implement is transported without the transport frame.

Transport running gear

1. Align the centre line eradicator **4** in the bracket **1**.
2. Secure the centre line eradicator with the pin **2**.
3. Secure the pin with a linch pin **3**.




CMS-I-00002977

### 6.5.7 Adjusting the section end position

CMS-T-00010033-A.1

The end position of the sections is pre-set so that the implement sections are horizontal during operation. This setting can be adapted to the operating conditions.

1. Raise the implement.
  2. *To engage the transport lock,* fold the implement sections.
  3. Loosen the lock nut **3**.
  4. Move the setting screw **1** to the desired position.
  5. Unfold the implement sections.
- ➔ The setting screws must touch the contact surface **2** simultaneously.
6. Tighten the lock nuts.
  7. Make the same setting for the opposite side of the implement.




CMS-I-00006836

### 6.5.8 Adjusting the scraper on the roller

CMS-T-00000076-H.1


The scrapers are set at the factory. The setting must be adapted to the soil conditions.



CMS-I-00002071

Roller	Possible scraper distance <b>A</b>	Recommended scraper distance <b>A</b> for sticky soils
Wedge ring roller KW / KWM	10 mm to 15 mm	10 mm
Tooth packer roller PW	1 mm to 4 mm	1 mm
Trapeze ring roller TRW	1 mm to 4 mm	1 mm

1. Read the scraper distance **A** from the table.
2. Loosen the bolt **1** on the scraper **2**.
3. Move the scraper in the elongated slot.
4. Tighten the bolt **1**.
5. *To check the distances when the implement is lowered:*  
Rotate the roller.



CMS-I-00000521

## 6.6 Preparing the machine for road travel

CMS-T-00010028-C.1

### 6.6.1 Folding the implement


CMS-T-00010029-B.1

1. Raise the implement.



**IMPORTANT** Damage to the universal joint shaft by tension in the drive

- ▶ *Before you fold the implement:*  
Wait until moving implement parts have come to a standstill.
- ▶ Move the tractor's PTO shaft drive to the neutral position.
- ▶ *Depending on the tractor equipment:*  
Disconnect the PTO shaft brake of the tractor.



CMS-I-00006834

2. *Until the implement sections have reached the end position,*  
Actuate the "green 2" tractor control unit.
3. *When the frame transport lock **2** is engaged,*  
release the pull rope **1** and put the tractor control unit to the neutral position.

## 6 | Preparing the machine


### Preparing the machine for road travel

The roller transport lock **1** secures the carrying arms of the trailing roller **2** in a folded state.

4. Before driving off, check that the roller transport lock is engaged.

or

*If the roller transport lock is not engaged, move the roller outwards until the roller transport lock engages.*



CMS-I-00006828

### 6.6.2 Switching off the work lights

CMS-T-00013341-C.1

- *To avoid blinding other road users, switch off the work lights according to "ISOBUS" operating manual*

or

*"control computer" operating manual*

or

using the rocker switch.

# Using the machine

# 7

CMS-T-00010022-B.1

## 7.1 Unfolding the implement

CMS-T-00010023-B.1

1. Raise the implement.
2. Actuate the "green 2" tractor control unit.


➔ The transport lock is unloaded.



**IMPORTANT** Damage to the universal joint shaft by tensioning the drive

- ▶ Before folding the implement, disconnect the PTO shaft brake of the tractor.

3. *Until the implement sections have reached the end position,*  
Actuate the pull rope and actuate the "green 1" tractor control unit.
4. *When the implement sections have reached the end position,*  
Release the pull rope and put the tractor control unit into float position.



CMS-I-00006834

## 7.2 Using the implement

CMS-T-00009290-B.1

1. Lower the implement until it is just above the field.

When working with the implement switched on, it must be ensured that the tines touch the soil.

2. Switch on the tractor PTO shaft.
3. Lower the implement on the field.
4. Move the hydraulic system of the three-point power lift into float position.

## 7.3 Checking the set working depth

CMS-T-00004568-A.1

If the set working depth is greater than the tine length, the tool carriers are constantly working in the soil horizon.



### IMPORTANT

**The tool carriers become worn when constantly working in the soil.**

- ▶ Replace the tines before they reach the minimum length.
  
- ▶ *To prevent wear of the tool carriers, check the set working depth after driving a short distance.*

## 7.4 Turning on the headlands

CMS-T-001728-C.1

1. *To prevent lateral loads when driving in curves on the headlands:*  
raise the soil tillage tools.
  
2. *When the direction of the implement matches that of the direction of travel:*  
lower the soil tillage tools.

## Eliminating faults

# 8

CMS-T-00010077-D.1

Errors	Cause	Solution
The trailing roller rotates stiffly during initial operation.	Production-related paint residues make it difficult for the roller to rotate.	▶ Pull the roller over firm ground.
Tines stopping during operation	If the tines encounter an obstacle, the tool carriers are blocked.	▶ see page 64
	After the tines have encountered an obstacle, the obstacle is jammed between the tines. The cam-type clutch does not engage automatically.	▶ see page 64
The cam-type clutch is often triggered	Maintenance is required on the cam-type clutch.	▶ see page 64
	Excessive torques on the cam-type clutch.	▶ see page 65
The lighting for road travel has a malfunction.	Lamp or lighting supply line is damaged.	▶ Replace the lamp. ▶ Replace the lighting supply line.
The additional fan on the oil cooler is not rotating	Malfunction of the additional fan regulation.	▶ see page 65
The wheel mark eradicator collision protection is triggered	The wheel mark eradicator has encountered a solid obstacle. The shear bolt is torn and the wheel mark eradicator folded to the rear.	▶ see page 65
It lowers the wrong track marker.	When actuating the tractor control unit, the wrong track marker is lowered.	▶ Switch the control unit several times.

### Tines stopping during operation

CMS-T-00004519-C.1

#### **If the tines encounter an obstacle, the tool carriers are blocked.**

The tines encountered an obstacle, the tool carriers are blocked:

1. Raise the implement.
2. Reduce the PTO shaft speed to approx. 300 1/ min.

➔ The cam-type clutch engages audibly.

3. Re-establish the original PTO shaft speed.
4. Resume working.

#### **After the tines have encountered and obstacle, the obstacle is jammed between the tines. The cam-type clutch does not engage automatically.**

An obstacle is jammed between the tines:

1. Raise the implement.
2. Secure the tractor and implement.
3. Wait until the tool carriers come to a stop.
4. Remove the obstacle between the tines.

### The cam-type clutch is often triggered

CMS-T-00004943-B.1

#### **Maintenance is required on the cam-type clutch.**

Maintenance is required on the cam-type clutch:

1. *If the cam-type clutch is often triggered,* perform maintenance according to the instructions from the universal joint shaft manufacturer

or

Contact AMAZONE Customer Service.

2. Install the universal joint shafts.

### Excessive torques on the cam-type clutch.

Excessive torques on the cam-type clutch:

Universal joint shaft speeds lower than 1000 rpm cause high torques on the cam-type clutch.

- ▶ *If the cam-type clutch is often triggered,* set the speed of the universal joint shaft to 1000 rpm.

### The additional fan is not rotating

CMS-T-00004172-B.1

1. Disconnect the power supply.
  2. Allow the regulator for the additional fan to cool down.
  3. Reconnect the power supply.
- ➔ As soon as voltage is applied to the 12V socket, the additional fan starts rotating.
4. *If the additional fan does not rotate,* please contact your AMAZONE customer service.

### The wheel mark eradicator collision protection is triggered

CMS-T-00006305-C.1


1. Remove the spare bolts **1** from the track marker bracket.
2. Remove the damaged bolt **3**.
3. Fold the wheel mark eradicator **2** into working position.



#### NOTE

Only use original bolts as a replacement.

4. Install the spare bolt.
5. Install the nut and tighten it.



CMS-I-00004507

# Parking the machine

# 9

CMS-T-00010010-D.1

## 9.1 Unfolding the implement

CMS-T-00010023-B.1

1. Raise the implement.
2. Actuate the "green 2" tractor control unit.


➔ The transport lock is unloaded.



**IMPORTANT** Damage to the universal joint shaft by tensioning the drive

▶ Before folding the implement, disconnect the PTO shaft brake of the tractor.

3. *Until the implement sections have reached the end position,*  
Actuate the pull rope and actuate the "green 1" tractor control unit.
4. *When the implement sections have reached the end position,*  
Release the pull rope and put the tractor control unit into float position.



CMS-I-00006834

## 9.2 Lowering the implement

CMS-T-00004165-A.1



### REQUIREMENTS

- ☑ The implement is unfolded



### IMPORTANT


The centre line eradicator penetrates deeper into the soil than the tool tines

- ▶ To prevent damage to the centre line eradicator, do not lower the centre line eradicator onto solid ground.
  - ▶ The centre line eradicator must penetrate into loose soil.
- 
- ▶ Park the implement sections on a level surface with solid ground.

## 9.3 Uncoupling the lighting for road travel


CMS-T-00001402-I.1

1. Unplug the connector **1** for the lighting.



CMS-I-00001048

2. Hook in the plugs **1** in the hose cabinet.




CMS-I-00001248

## 9.4 Disconnecting the hydraulic hose lines


CMS-T-00000277-F.1

1. Secure the tractor and implement.
2. Put the control lever on the tractor control unit in float position.
3. Disconnect the hydraulic hose lines **1**.
4. Put the dust caps on the hydraulic sockets.



CMS-I-00001065

5. Hang the hydraulic hose lines **1** in the hose cabinet.




CMS-I-00001250

## 9.5 Uncoupling the universal joint shaft

CMS-T-00001843-C.1

1. Remove the safety chain **2** from the tractor.
2. Pull on the pull sleeve **1** of the universal joint shaft.
3. Pull off the universal joint shaft from the tractor PTO shaft.
4. Place the universal joint shaft in its holder on the implement.




CMS-I-00001069

## 9.6 Uncoupling the three-point mounting frame

CMS-T-00001401-D.1

1. Park the implement on a level surface with solid ground.
2. Release the top link **1**.
3. Uncouple the top link from the implement.
4. Release the lower links **2**.
5. Uncouple the lower links from the implement from the tractor seat.



CMS-I-00001249

# Repairing the machine

# 10

CMS-T-00010024-E.1

## 10.1 Maintaining the machine

CMS-T-00010083-D.1

### 10.1.1 Maintenance schedule

<b>After initial operation</b>	
Checking the hydraulic hose lines	see page 71
Checking and adjusting the scraper on the roller	see page 74
Checking the oil level in the interchangeable wheel gear	see page 75
Checking the oil level in the centre gearbox	see page 76
Checking the oil level in the spur gear trough	see page 77
<b>After the first 50 operating hours</b>	
Replacing the oil in the interchangeable wheel gear	see page 78
Replacing the oil in the centre gearbox	see page 78
<b>As required</b>	
Replacing the tines	see page 73
<b>Daily</b>	
Checking the lower link pins and top link pins	see page 71
<b>Every 6 months</b>	
Ratchet clutch maintenance	see page 80
<b>Every 50 operating hours</b>	
Checking the tines	see page 72
Universal joint shaft maintenance	see page 80
<b>Every 100 operating hours</b>	
Checking and adjusting the scraper on the roller	see page 74

Every 500 operating hours	
Replacing the oil in the interchangeable wheel gear	see page 78
Replacing the oil in the centre gearbox	see page 78

Every 50 operating hours / Weekly	
Checking the hydraulic hose lines	see page 71
Checking the oil level in the interchangeable wheel gear	see page 75
Checking the oil level in the centre gearbox	see page 76
Checking the oil level in the spur gear trough	see page 77

### 10.1.2 Checking the lower link pins and top link pins

CMS-T-00002330-K.1

#### INTERVAL

- Daily

#### Criteria for visual inspection of lower link pins and top link pins:

- Cracks
  - Fractures
  - Permanent deformations
  - Permissible wear: 2 mm
1. Check the lower link pins and top link pins for the listed criteria.
  2. Replace worn pins.

### 10.1.3 Checking the hydraulic hose lines

CMS-T-00002331-G.1

#### INTERVAL

- After initial operation
  - Every 50 operating hours
- or
- Weekly


1. Check the hydraulic hose lines for damage, such as chafing point, cuts, tears and deformation.
2. Check the hydraulic hose lines for leaks.
3. Retighten loose bolted connections.

## 10 | Repairing the machine

### Maintaining the machine

Hydraulic hose lines must not be more than 6 years old.

4. Check the manufacturing date **1**.



CMS-I-00000532



### WORKSHOP WORK

5. Replace worn, damaged or aged hydraulic hose lines.


### 10.1.4 Checking the tines

CMS-T-00005050-B.1



### INTERVAL

- Every 50 operating hours
1. Determine the length of the tines.
  2. *If the minimum length of the tines is undercut, replace the tines.*



CMS-I-00003613


### 10.1.5 Replacing the tines

CMS-T-00004140-B.1

 **INTERVAL**

- As required


1. Remove the linch pin **3**.
2. Remove the pin **1** from the tool carrier.
3. Remove the tine **2**.



CMS-I-00003035

 **NOTE**

The outer tool carriers **1** always rotate towards the centre of the implement.



CMS-I-00003470

4. Pay attention to the alignment of the tine.
5. Install the new tine **2**.
6. Fasten the tine with the pin.
7. Secure the tine with the linch pin.

### 10.1.6 Checking and adjusting the scraper on the roller

CMS-T-00018820-C.1




#### INTERVAL

- After initial operation
- Every 100 operating hours

The scrapers are subject to wear. The scrapers can be readjusted.

Roller	Scraper distance <b>A</b>
Wedge ring roller KW / KWM	10 mm to 15 mm
Tooth packer roller PW	1 mm to 4 mm
Trapeze ring roller TRW	1 mm to 4 mm



CMS-I-00002071

1. Read the scraper distance **A** from the table.

2. Loosen the bolt **1** on the scraper **2**.


3. Move the scraper in the elongated slot

or

*If the scraper cannot be readjusted any more:  
Replace and adjust the scraper.*

4. Tighten the bolt **1**.

5. *To check the distances when the implement is lowered:  
Rotate the roller.*



CMS-I-00000521

### 10.1.7 Checking the oil level in the interchangeable wheel gear

CMS-T-00004632-B.1



#### INTERVAL

- After initial operation
- Every 50 operating hours  
or  
Weekly

1. Park the implement on a horizontal surface.
2. Remove the oil dipstick **1**.
3. Check the oil level.




#### NOTE

If oil types are mixed, warranty claims cannot be accepted.

- Do not mix oils.
- Fill with new and clean gear oil.

4. *If the oil level is not visible between the markings **2**,*  
Refill the oil.
5. *When the oil level is visible between the markings,*  
install the oil dipstick with a new sealing ring.



CMS-I-00003466

### 10.1.8 Checking the oil level in the centre gearbox

CMS-T-00010086-A.1



#### INTERVAL

- After initial operation
  - Every 50 operating hours
- or
- Weekly




#### ENVIRONMENTAL INFORMATION

##### Danger due to escaping oil

- ▶ Collect any escaping oil.
- ▶ Dispose of cleaning agents for removing oil in an environmentally friendly manner.

1. Park the implement on a horizontal surface.
2. Remove the ventilation **1**.
3. Remove the bolt **2**.



CMS-I-00006847



#### NOTE

If oil types are mixed, warranty claims cannot be accepted.

- Do not mix oils.
  - Fill with new and clean gear oil.
4. Refill oil through the ventilation opening.
- ➔ When oil emerges from the thread of the bolt, the correct oil level has been reached.
5. Install the bolt.
  6. Install the ventilation.

### 10.1.9 Checking the oil level in the spur gear trough

CMS-T-00004838-B.1



#### INTERVAL

- After initial operation
  - Every 50 operating hours
- or
- Weekly




#### IMPORTANT

##### Damage due to impurities in the spur gear trough

- ▶ Clean the implement before performing maintenance.

1. Park the implement on a horizontal surface.
2. Loosen and remove the nut **2**.
3. Remove the cover bolt **1**.
4. Remove the cover with ventilation pipe **4**.



CMS-I-00003467



#### NOTE

If oil types are mixed, warranty claims cannot be accepted.

- Do not mix oils.
  - Fill with new and clean gear oil.
5. *If the spur gears are not halfway covered with gear oil in the spur gear trough, refill oil according to the technical data.*
  6. Check the fit of the gasket **3**.
  7. Install the cover with the ventilation pipe.
  8. Install the cover bolt.
  9. Install the nut and tighten it.



#### NOTE

There is no need to change the oil in the spur gear trough.

### 10.1.10 Replacing the oil in the interchangeable wheel gear

CMS-T-00004631-B.1



#### INTERVAL


- After the first 50 operating hours
- Every 500 operating hours

1. Place a suitable collection bucket under the oil drain opening.
2. Remove the oil dipstick **1**.
3. Remove the oil drain plug **2**.



#### ENVIRONMENTAL INFORMATION Danger due to escaping oil

- ▶ Collect any escaping oil.
- ▶ Dispose of cleaning agents for removing oil in an environmentally friendly manner.



CMS-I-00003465

4. Install the oil drain plug with a new sealing ring.
5. Refill the oil.
6. install the oil dipstick with a new sealing ring.

### 10.1.11 Replacing the oil in the centre gearbox


CMS-T-00010087-A.1



#### INTERVAL


- After the first 50 operating hours
- Every 500 operating hours

1. Park the implement on a horizontal surface.
2. Remove the ventilation **1**.



CMS-I-00006846

3. Place a suitable collection bucket under the oil drain opening.
4. Remove the oil drain plug **1**.
5. *When all of the oil has been drained,*  
Install the oil drain plug with a new sealing ring.



CMS-I-00006843




## ENVIRONMENTAL INFORMATION

### Danger due to escaping oil

- ▶ Collect any escaping oil.
- ▶ Dispose of cleaning agents for removing oil in an environmentally friendly manner.

6. Remove the bolt **2**.
7. Refill oil through the ventilation opening.  
➔ When oil emerges from the thread of the bolt, the correct oil level has been reached.
8. Install the bolt.
9. Install the ventilation **1**.



CMS-I-00006847

### 10.1.12 Ratchet clutch maintenance


CMS-T-00004584-A.1



#### INTERVAL

- Every 6 months

- ▶ Perform maintenance on the ratchet clutches **1** according to the instructions from the universal joint shaft manufacturer



CMS-I-00003044

### 10.1.13 Universal joint shaft maintenance

CMS-T-00004585-B.1



#### INTERVAL

- Every 50 operating hours

- ▶ Perform maintenance on the universal joint shaft according to the instructions from the universal joint shaft manufacturer.

## 10.2 Lubricating the implement


CMS-T-00010025-C.1



### IMPORTANT

#### Implement damage due to improper lubrication


- ▶ Grease the implement at the marked lubrication points according to the lubrication schedule.
- ▶ *To ensure that dirt is not pressed into the lubrication points,* thoroughly clean the grease nipples and the grease gun.
- ▶ Only grease the implement with the lubricants listed in the technical data.
- ▶ Press the dirty grease completely out of the bearings.



CMS-I-00002270


10.2.1 Overview of lubrication points

CMS-T-00010026-A.1




CMS-I-00006837


Every 50 operating hours / Every 6 months



CMS-I-00006853



CMS-I-00003006



CMS-I-00006854

### 10.3 Cleaning the implement

CMS-T-00000593-G.1



#### IMPORTANT

##### Risk of machine damage due to cleaning jet of the high-pressure nozzle

- ▶ Never direct the cleaning jet of the high-pressure cleaner or hot water high-pressure cleaner onto the marked components.
  - ▶ Never aim the cleaning jet of high-pressure cleaners or hot water high-pressure cleaners on electrical or electronic components.
  - ▶ Never aim the cleaning jet of the high pressure cleaner directly on lubrication points, bearings, rating plates, warning signs, and stickers.
  - ▶ Always maintain a minimum distance of 30 cm between the high-pressure nozzle and the implement.
  - ▶ Do not exceed a water pressure of 120 bar.
- 
- ▶ Clean the implement with a high-pressure cleaner or a hot water high-pressure cleaner.



CMS-I-00002692

## 10.4 Storing the implement

CMS-T-00005282-A.1



### IMPORTANT

#### Implement damage due to corrosion

Dirt attracts moisture and leads to corrosion.

- ▶ Store the implement only in a clean state and protected from the weather.

1. Clean the machine.
2. Protect unpainted components from corrosion using a suitable corrosion inhibitor.
3. Grease all lubrication points. Remove excess grease.
4. Park the implement in a sheltered place.

# Loading the implement

# 11

CMS-T-00010035-C.1

## 11.1 Loading the implement with a crane

CMS-T-00010036-B.1

The implement has 3 lashing points for slings for lifting.




### WARNING

**Risk of accidents due to improperly attached slings for lifting**

If the slings are not attached at the marked lashing points, the implement can be damaged during lifting and endanger safety.

- ▶ Only attach the slings for lifting at the marked lashing points.



CMS-I-00006882



### REQUIREMENTS

- ☑ The implement is unfolded

1. Attach the slings for lifting on the intended lashing points.
2. Slowly lift the implement.

## 11.2 Manoeuvring the implement onto a transport vehicle

CMS-T-00012331-A.1

- ▶ Manoeuvre the implement in reverse with a shunting vehicle onto a transport vehicle.

## 11.3 Lashing the implement

CMS-T-00010037-B.1

The implement has 3 lashing points **1** for lashing straps.




### WARNING

#### Risk of accidents due to improperly attached lashing straps

If the lashing straps are not attached at the marked lashing points, the implement can be damaged during lashing and endanger safety.

- ▶ Attach the lashing straps only at the marked lashing points.



CMS-I-00006881



### REQUIREMENTS

- ☑ The implement is unfolded

1. Put the implement on the transport vehicle.
2. Attach the lashing straps at the marked points.
3. Lash down the implement in compliance with the national regulations for load securing.

# Disposing of the implement

# 12

CMS-T-00010906-B.1




## ENVIRONMENTAL INFORMATION

### Environmental damage due to improper disposal

- ▶ Observe the regulations of the local authorities.
- ▶ Observe the symbols on the implement regarding disposal.
- ▶ Observe the following instructions.

1. Components with this symbol should not be disposed of with household waste.



CMS-I-00007999

2. Return batteries to the distributor  
or  
Dispose of batteries at a collection point.
3. Put recyclable materials in the recycling.
4. Treat operating materials like hazardous waste.



## WORKSHOP WORK

5. Dispose of the coolant.


# Appendix

# 13

CMS-T-00004152-D.1

## 13.1 Bolt tightening torques

CMS-T-00000373-G.1




CMS-I-000260

**NOTE**

Unless specified otherwise, the bolt tightening torques listed in the table apply.

M	S	Strength classes		
		8.8	10.9	12.9
M8	13 mm	25 Nm	35 Nm	41 Nm
M8x1		27 Nm	38 Nm	41 Nm
M10	16 (15,17) mm	49 Nm	69 Nm	83 Nm
M10x1		52 Nm	73 Nm	88 Nm
M12	18 (19) mm	86 Nm	120 Nm	145 Nm
M12x1.5		90 Nm	125 Nm	150 Nm
M14	22 (21) mm	135 Nm	190 Nm	230 Nm
M 14x1.5		150 Nm	210 Nm	250 Nm
M16	24 mm	210 Nm	300 Nm	355 Nm
M16x1.5		225 Nm	315 Nm	380 Nm
M18	27 mm	290 Nm	405 Nm	485 Nm
M18x1.5		325 Nm	460 Nm	550 Nm
M20	30 mm	410 Nm	580 Nm	690 Nm
M20x1.5		460 Nm	640 Nm	770 Nm

M	S	Strength classes		
		8.8	10.9	12.9
M22	32 mm	550 Nm	780 Nm	930 Nm
M22x1.5		610 Nm	860 Nm	1,050 Nm
M24	36 mm	710 Nm	1,000 Nm	1,200 Nm
M24x2		780 Nm	1,100 Nm	1,300 Nm
M27	41 mm	1,050 Nm	1,500 Nm	1,800 Nm
M27x2		1,150 Nm	1,600 Nm	1,950 Nm
M30	46 mm	1,450 Nm	2,000 Nm	2,400 Nm
M30x2		1,600 Nm	2,250 Nm	2,700 Nm



CMS-I-0000065

M	Tightening torque	M	Tightening torque
M4	2.4 Nm	M14	112 Nm
M5	4.9 Nm	M16	174 Nm
M6	8.4 Nm	M18	242 Nm
M8	20.4 Nm	M20	342 Nm
M10	40.7 Nm	M22	470 Nm
M12	70.5 Nm	M24	589 Nm

## 13.2 Other applicable documents

CMS-T-00004153-A.1

- Tractor operating manual
- Universal joint shaft operating manual

# Directories

# 14

## 14.1 Glossary

CMS-T-00000513-B.1

### M

#### Machine

*Mounted implements are accessory parts of the tractor. However, mounted implements are always referred to as the implement in this operating manual.*

### O

#### Operating materials

*Operating materials serve to ensure operational readiness. Operating materials include e.g. cleaning agents and lubricants such as lubricating oil, greases or cleaners.*

### T

#### Tractor

*In this operating manual, the designation tractor is always used, even for other agricultural tractor units. Implements are mounted on the tractor or towed by the tractor.*

## 14.2 Index

<b>A</b>		Frame transport lock	24
Additional license plate	35	Front axle load <i>calculation</i>	42
Address		Front ballasting <i>calculation</i>	42
<i>Technical editing</i>	4	Front lighting <i>Description</i>	34
Adjusting the section end position	58	Function of the implement	22
Adjusting the spring tension		<b>H</b>	
<i>Side guide plates</i>	55	Headlands	62
Adjusting the working height		Hydraulic hose lines	
<i>Levelling board</i>	52	<i>checking</i>	71
Adjust the working depth		<i>coupling</i>	48
<i>Side guide plates, extendable</i>	53	<i>uncoupling</i>	68
<i>Tine, manual</i>	51	Hydraulic system	
Aids	31	<i>coupling</i>	48
<b>B</b>		<b>I</b>	
Backstop profiles for lower links		Identification for road travel	
<i>attachment</i>	45	<i>Front</i>	34
Bolt tightening torques	88	<i>Rear</i>	34
<b>C</b>		Implement	
Changing the oil		<i>folding</i>	59
<i>Oils and filling capacities</i>	39	<i>unfolding</i>	61, 66
Checking the oil level		Implement overview	21
<i>Spur gear trough</i>	77	Intended use	20
Checking the set working depth	62	<b>L</b>	
cleaning		Levelling board	
<i>Implement</i>	83	<i>Adjusting the working height</i>	52
Contact data		Lighting for road travel	
<i>Technical editing</i>	4	<i>connecting</i>	50
<b>D</b>		<i>disconnecting</i>	67
Dimensions	37	<i>Front</i>	34
Documents	31	<i>Rear</i>	34
<b>E</b>		Loading	
Eliminating faults	63	<i>lashing</i>	86
<b>F</b>		<i>manoeuvring onto a transport vehicle</i>	85
Folding	59	<i>with a crane</i>	85
		Loads	
		<i>calculation</i>	42

Lowering the implement	67	Product description	
Lower link pin		<i>Additional license plate</i>	35
<i>checking</i>	71	<i>Function of the implement</i>	22
Lubricants	39	<i>Special equipment</i>	23
		<i>Universal joint shaft locking mechanism</i>	33
<b>M</b>		Protective equipment	
Maintenance		<i>Universal joint shaft guard</i>	23
<i>Checking the oil level in the spur gear trough</i>	77	<b>R</b>	
<i>Checking the tines</i>	72	Ratchet clutch	33
<i>Ratchet clutch maintenance</i>	80, 80	Rating plate	
<i>Replacing the tines</i>	73	<i>Description</i>	32
Mounting category	37	Rear axle load	
<b>N</b>		<i>calculation</i>	42
Noise development data	38	Rear lighting	
<b>O</b>		<i>Description</i>	34
Oil		Repairing the machine	
<i>Checking the oil level in the centre gearbox</i>	76	<i>Eliminating faults</i>	63
<i>Checking the oil level in the interchangeable</i>		Roller	
<i>wheel gear</i>	75	<i>Adjusting the scraper</i>	58
<i>replacement in the centre gearbox</i>	78	<i>Checking and adjusting the scraper</i>	74
<i>replacing in the interchangeable wheel gear</i>	78	Roller transport lock	25
Operation	61	<b>S</b>	
Optimal working speed	37	Scraper	
Overwintering	84	<i>adjustment</i>	58
<b>P</b>		<i>checking and adjusting</i>	74
Parking the implement		Special equipment	23
<i>Uncoupling the universal joint shaft</i>	68	Storage	84
Parking the machine		<b>T</b>	
<i>Lowering the implement</i>	67	Technical data	
Payload		<i>drivable slope inclination</i>	39
<i>calculation</i>	41, 50	<i>Lubricants</i>	39
Performance characteristics of the tractor	38	<i>Mounting category</i>	37
Permissible total weight	37	<i>Noise development data</i>	38
Permissible transport speed	37	<i>Oils and filling capacities</i>	39
Preparing the implement for operation		<i>Permissible payload</i>	41
<i>Adjusting the speed of the tines</i>	56	<i>Working depth</i>	38
<i>Adjusting the working height of the levelling</i>		Threaded cartridge	
<i>board</i>	52	<i>Description</i>	31
<i>Using the centre line eradicator</i>	57	Three-point mounting frame	32
		<i>coupling</i>	48
		<i>uncoupling</i>	69

Tine	
<i>checking</i>	72
<i>replacing</i>	73
Tool protection	24
Top link pin	
<i>checking</i>	71
Total weight	
<i>calculation</i>	42
Tractor	
<i>Calculating the required tractor characteristics</i>	42
Transport speed	
<i>Permissible</i>	37
Tyre load capacity	
<i>calculation</i>	42

## U

Uncoupling the universal joint shaft	68
Unfolding	61, 66
Universal joint shaft guard	23
Universal joint shaft	
<i>coupling</i>	50
<i>installing</i>	45, 46
<i>preparing</i>	45
<i>Ratchet clutch maintenance</i>	80
<i>Universal joint shaft maintenance</i>	80
Universal operating tool	
<i>Description</i>	33
Using the centre line eradicator	57
Using the machine	
<i>Checking the set working depth</i>	62

## W

Warning symbols	25
<i>Description of the warning symbols</i>	27
<i>Layout</i>	26
<i>Positions of the warning symbols</i>	25
Working depth	38
Working speed	37
Work lights	
<i>switching off</i>	60
Workshop work	3







**AMAZONE**

**AMAZONEN-WERKE**

H. DREYER SE & Co. KG

Postfach 51

49202 Hasbergen-Gaste

Germany

+49 (0) 5405 501-0

[amazone@amazone.de](mailto:amazone@amazone.de)

[www.amazone.de](http://www.amazone.de)